




PLL ALARM CLOCK RADIO WITH USB MP3 PLAYBACK, BLUETOOTH AND DUAL USB CHARGING (2.4A and 1A)



Model :HX-129CR

QUICK REFERENCE



1. SNOOZE BUTTON

- Use this button to temporarily suspend the ALARM for a short period.

2. LED DISPLAY

3. PM INDICATOR (This indicator shows that the time display is PM)

4. AL1-B INDICATOR (This indicator shows that the unit is in ALARM-1 buzzer mode.)

5. AL1-R INDICATOR (This indicator shows that the unit is in ALARM-1 radio mode.)

6. AL2-B INDICATOR (This indicator shows that the unit is in ALARM-2 buzzer mode.)

7. AL2-R INDICATOR (This indicator shows that the unit is in ALARM-2 radio mode.)

8. ⏻ /FUNC./AL OFF BUTTON

- Use this button to select different function modes (FM radio / Bluetooth /Aux-in/USB).
- When alarm activates, press this button to turn off.

9. Bluetooth Pair/ ▶ || / FM SCAN BUTTON

- In USB/Bluetooth mode, use this button to play or pause the music playing
- In FM radio mode, use this button to scan the whole FM Band and store 20 presets station

10. MEM / +10 BUTTON

- In USB/Bluetooth mode, use this button to skip 10 tracks.
- In FM radio mode, use this button to store 20 presets station manually.

11. ⏮ / HR BUTTON

- In RADIO mode, use this button to search the radio station in forward direction.
- In USB/Bluetooth mode, Use this button to skip to the next track.
- In CLOCK mode, use this button to adjust the "hour" in CLOCK or ALARM time.

12. VOL+/AL1 BUTTON

- In Radio/ USB/ Bluetooth mode, use this button to increase the volume.
- In CLOCK mode, use this button to set the alarm time in ALARM 1

13. VOL-/AL2 BUTTON

- In Radio/ USB/ Bluetooth mode, use this button to decrease the volume.
- In CLOCK mode, use this button to set the alarm time in ALARM 2

14. SLEEP BUTTON

- Use this button to set the SLEEP timer between 10 and 90 minutes

15. ■ BUTTON

- In USB mode, Use this button to stop playing the MP3.

16. TIME/M+ BUTTON

- Press and hold this button to set the time.
- In Radio mode, use this button to listen the preset stations.

17. ⏮ / MIN BUTTON

- In Radio mode, use this button to search the radio station in backward direction.
- In USB/Bluetooth mode, use this button to skip back to the previous track.
- In CLOCK mode, use this button to adjust the minute in CLOCK or ALARM time.

18. USB Charging Port

- Connect a USB cable to charge your device. (Current: 2.4A)

19. USB Charging Port (1A) and MP3 playback

- Connect a USB cable to charge your device (Current : 1A)
- In USB Mode, plug the USB memory stick to play MP3.

20. Bluetooth Indicator (This indicator shows the BLUETOOTH status)

21. SPEAKERS

22. BATTERY COMPARTMENT (Compartment for the back-up battery.)

23. FM WIRE ANTENNA (Extent this wire antenna to obtain better FM broadcasting.)

24. DC JACK (Connect the unit to the AC/DC adaptor.)

25. LINE IN JACK (Connect the aux-in cable)

SPECIFICATIONS

Frequency Range: FM 87.5 – 108 MHz

Power Supply: AC 100-240V ~ 60/50 Hz

AC/DC adaptor 5V $\overline{\text{---}}$ 3.5A

Back-Up Battery: 2 pc. UM4 'AAA' size (not included)

CONNECTING THE UNIT TO POWER

Plug one end of the AC adaptor into the DC power Input, and then plug the other end into AC wall outlet. Before switching on the unit, make sure that the voltage of your electricity supply is the same as that indicated on the rating plate.

BATTERY BACKUP (for memory backup)

Insert two pieces UM-4 batteries into the battery compartment. Be sure to observe the proper polarity (the "+" and "-" signs) as indicated inside the battery compartment.

In case of power failure or interrupted AC power, the current time and alarm time settings, the stored radio stations are preserved in the memory of the unit by means of battery back-up function.

SETTING THE CLOCK

1. With the unit in CLOCK mode, press the and hold the **TIME/M+** button, the time will begin to flash on the LED display.
2. Press the **⏮ /HR** button to adjust the hour.
3. Press the **⏮ /MIN** button to adjust the minute.
4. When the correct time is selected, press the **TIME/M+** button again to confirm.

SETTING THE ALARMS

1. With the unit in **CLOCK** mode, press the **VOL+/AL1** or **VOL-/AL2** button. The **ALARM** time will begin to flash on the LED display.
2. Press the **▶/HR** button to adjust the alarm hour.
3. Press the **◀/MIN** button to adjust the alarm minute.
4. When the correct alarm time is selected, press the **VOL+/AL1** or **VOL-/AL2** button to confirm.
5. Press the **VOL+/AL1** or **VOL-/AL2** repeatedly to select the **ALARM** sound mode - buzzer or currently set radio station. The corresponding alarm buzzer or radio indicator will light up.

SNOOZE FUNCTION

1. Whenever the alarm (radio or buzzer) activates, it can be temporarily suspended for a short period of 9 minutes by pressing the **SNOOZE** button once.
2. The alarm will then automatically activate again after the 9 minutes **SNOOZE** period has ended.
3. This procedure can be repeated for up to approximately one hour.

TURN OFF THE ALARM

When the Alarm activate, press the **⏻ /FUNC/ AL OFF** button to turn off the Alarm.

LISTENING TO THE FM RADIO

1. Press and hold the **⏻ /FUNC. /AL.OFF** button to go in to Function mode.
2. Press the **⏻ /FUNC./AL.OFF** button repeatedly to select the **RADIO** mode
3. Press the **▶/HR** or **◀/MIN** buttons step by step to tune to the desired radio stations.
4. Press and hold the **▶/HR** or **◀/MIN** buttons for approx. 1 second, it will start to search the next radio station in the direction of the search. The search operation simply finds stations with strong signals. Stations with weak reception can only be tuned in manually.

Note : For best reception, fully extend the FM wire antenna to receive FM stations.

STORING RADIO STATION TO THE MEMORY (FULL SCAN)

1. In radio mode, press and hold **Bluetooth Pair/ ▶ II / FM SCAN** button.
2. It will scan the whole FM band and store the first 20 available preset stations in memory.
3. You can store other preset stations manually.

SAVING A RADIO STATION TO THE MEMORY (MANUAL TUNING)

1. In radio mode, tune the radio to the desired station.
2. Press the **MEM/+10** button for approx. 1 second, the LED display will show **PXX** and flash (XX is the memory station number)
3. Press the **▶/HR** or **◀/MIN** buttons to select the desired preset station number.
4. Press the **MEM/+10** button again to store the radio station in the memory..
5. Up to 20 FM radio stations can be stored in the memory.
6. To turn off the radio function, press and hold **⏻ /FUNC. /AL.OFF** button or select other mode.


TO LISTEN TO A SAVED RADIO STATION

In radio mode, press the **TIME/M+** button to select the stored radio station.

USB MP3 PLAYBACK

1. Press and hold **⏻ /FUNC. /AL.OFF** button to go to function mode.
2. Press the **⏻ /FUNC. /AL.OFF** button repeatedly to select **USB** mode..
3. Plug your **USB** memory stick into the **USB** port on the unit, the unit will start reading the files in the **USB** device and play automatically.

****Please be reminded to plug your USB memory stick to the correct USB slot.**



BLUETOOTH STREAMING

1. Press and hold **⏻ /FUNC. /AL.OFF** button to go to function mode.
2. Press the **⏻ /FUNC. /AL.OFF** button repeatedly to select **Bluetooth** mode..
3. The **Bluetooth** indicator will start flashing indicating that the speaker is in pairing mode
4. Turn on the **Bluetooth** on your mobile phone or music player and perform a **Bluetooth** device scan. Select '**HX-129CR HANNLOMAX**' from the available **Bluetooth** device list.
5. If password needed, enter '0000' for pairing.
6. If the pairing is successful, the **Bluetooth** indicator will stay lighted. Now you can select and play the audio file from your mobile phone or music player.

AUTO PAIRING

Once the unit paired with the **Bluetooth** device, it will automatically pair with that device next time when you turn on the unit and that **Bluetooth** device.

Turn Off the Bluetooth Operation

To turn off the **BLUETOOTH** operation, press and hold **ON/OFF/AL RESET** button or select other mode.

PLAYING MUSIC THOUGH USB/BLUETOOTH

1. Press the **Bluetooth Pair/ ▶ II / FM** button to temporarily stop playing and press the **Bluetooth Pair/ ▶ II / FM** button again to resume playing.
2. Press the **▶/HR** button to skip to the next track.
3. Press the **◀/MIN** button to go to the previous track.
4. In **USB** mode, press **MEM/+10** button to skip 10 tracks.

AUX IN CONNECTION

1. Press and hold the **⏻ /FUNC. /AL.OFF** button to go in to Function mode.
2. Press the **⏻ /FUNC./AL.OFF** button repeatedly to select the **AUX** mode. **AUX** will display in the LED display for a few seconds.
3. Insert one side of the audio cable (requires 3.5mm stereo plug, not supplied) into the line-out jack or phones jack on your MP3 player or audio device and the other side to the line-in jack on the unit.
4. Turn on your MP3 player and follow the playback instruction.
5. To stop this function, simply turned off your MP3 player.

SLEEP TO MUSIC FUNCTION

1. This function allows you to listen to the radio or music (**USB/Aux-in/Bluetooth**) while you fall asleep.
2. Press the **SLEEP** button, the display will show the default sleep time of 90 minutes
3. Press the **SLEEP** button again to adjust the desired sleep time.
4. The options are 90-80-70-60-50-40-30-20-10-min. or **OFF**
5. Now you can enjoy listening to the radio for the pre-set period of sleep time.
6. After this pre-set time has elapsed, the unit will switch off automatically.

CHARGE YOUR DEVICES (2.4A and 1A)

Connect the standard size end of a **USB** cable (not included) to the **USB** ports on the unit and connect the other end to the charging port of your devices. The unit contains two **USB** ports (**2.4A and 1A).

Remarks: Some devices may not support **USB** charging or may require a higher power rating than this product provides. Observe the charging status on your device. Ensure your device is working properly before attempting to charge. Charging function may not be supported for all phones or electronic devices

